

Instructions: How to Move a Swing Door, MPR Refrigerator Through a 36" Wide Doorway

APPLIES TO MODEL NUMBERS MPR-1411-PA, MPR-1411R-PA.

PHCbi MPR-1411 and 1411R swing door refrigerators will fit through all doors with an opening 36.5" (with the earthquake brackets removed). Removal of a few freezer components will allow them to fit through most doorways with openings wider than 35.4".

To Remove Freezer Components for Doorway Clearance:

1. First, remove the two (2) black wall spacers, located on the rear of the unit to the sides of the grey, painted steel cover (pictured left). The spacers are attached with four (4) Phillips head screws.



2. Next, remove the black plastic drip pan (pictured below) by first removing the four (4) white plastic thumbscrews located below the pan.



3. Once the wall spacers and drip pan are removed, detach the grey metal cover by removing the eight (8) Phillips head screws.



4. The refrigerator can now be moved through the doorway for installation in the final location/room. Note: Care should be taken to prevent exposed refrigerant lines from catching on the door frame as the refrigerator is moved through the doorway.
5. Once the refrigerator is moved to its desired position, complete steps 1-3 in reverse to reinstall the removed components ensuring black wall spacers are also reinstalled as they establish adequate clearance needed for ventilation.

A video of the process is available at youtu.be/9uITYJexVXM.